

# Installation

**SV150T Light Source**

## ELECTRICAL/CONTROL SYSTEM

The Simple Sync is designed as an economical alternative for small to medium applications, involving 1 to 10 synchronous illuminators. Its purpose is to keep all illuminators in synchronous operation. Note: At all times the external power and color wheel switches should be in the "ON" position. When the Simple Sync is first powered up the color wheel will move to the "Home Position", allow up to 60 seconds for this operation, when all the illuminators reach the home position they will start to rotate in a synchronized operation. Note: For every complete rotation the color wheel will stop at the "Home position for 5 seconds, this will insure the synchronization of all the illuminators.

To insure proper synchronization:

- All light sources must be hooked up to the same circuit.
- All Light Sources must be turned on at the exact same time.
- Make sure the color wheel and power switch is in the "On position"

